


Sleep Operation

Please set this function when you want a quiet environment to rest.



Please set the following operation while the air-conditioner is running.





Press  button

Please set this function when you want a quiet environment to rest.

• To cancel sleep operation



Press  button again.

- The air flowing sound from the indoor unit becomes low immediately.
- In sleep operation, if  button is pressed, the sleep operation will be cancelled.

Caution:

- Please set this operation when you sleep. Because the environment temperature is too high, the cooling ability will become lower if you set this operation at daytime.