

Installation Note


Choice of Installation Site for Indoor Unit

- Keep away from heat source, steam source and inflammable gas.
- No blockage for the inlet and outlet vents to keep up good ventilation.
- Convenient drainage for drain hose.
- Convenient connection to outdoor unit.
- Install on a vibration-free and sturdy wall.
- Should be higher than eye level above the floor.
- Appliances which are intended to be maintained by qualified service personnel and located either in machine rooms and the like or at a level not less than 2.5m(98.43") or in secured rooftop areas.

Choice of Installation Site for Outdoor Unit

- Install on a sturdy and firm wall or on the floor
- Choose a well-ventilated place not subject to raining or direct sunlight
- Keep away from heat source and inflammable gas
- Exhalation should not affect neighbor.

Choice of Pipes



NOTE:

- The socket for the air-conditioner shall be installed where the plug is accessible easily.
- Arrange line according to national wiring regulation.