

Trial Run and Drainage Test

Trial run :

- Having confirmed that the wiring is in order, connect to electric supply for operation.
- Let the air-conditioner run for more than 15 minutes in cooling mode.
- Check the temperatures at the inlet and outlet vents.
- Ensure that the temperature difference between the inlet vent and outlet vent exceeds 8°C(47°F).

Drainage Test

Pour a cup of water to the water tray along the evaporator to check if the water drains out from the drainage hose.

