



37	Compressor terminal cover	1	305147002	305147002										
36	Compressor	1	960114069R	960114069R										
35	Anti-vibration pad for the compressor	1	110020036R	110020036R										
34	Compressor power cord	1	050040058R	050040058										
33	Valve installation plate	1	020020007R	020020007R										
32	High-pressure valve	1	060020190R	060020190R					16	Electric installation board	1	313120003	313120003	
31	Low-pressure valve	1	352260010R	352260010R					15	Compressor Capacitor	1	320120065	030010020	
30	Suction pipe	1	360160055R	360160056R					14	Small handle	1	100050018R	100050018R	
29	Anti-vibration pad	1	110020019R	110020019R					13	Top panel	1	020080035R	020080035R	
28	Discharge pipe	1	Cooling Only	Cooling Only					12	PU Sponge	3	090020310R	090020310R	
27	Large handle	1	100050022R	100050022R					11	Partition board	3	020030017R	020030017R	
26	Right panel	1	980150012R	980150012R					10	Pillar	1	029995101R	029995101R	
25	Capillary Assy	1	960800026R	971900250R					9	Left protect net	1	313990018R	313990018R	
24	4-way valve Assy	1		355100003R					8	Motor support	1	020040013R	020040013R	
23	Rear Grill	1	313100003R	313100003R					7	Motor	1	030020236	030020236	
22	Condenser	1	972200767R	972200751R					6	Axial flow fan	1	100030008R	100030008R	
21	PU Sponge	1	090010594R	090010594R					5	Gasket	1	453000011R	453000011R	
20	Wire Clip	1	321100004R	321100004R					4	Nut	1	150020003R	150020003R	
19	Terminal Board	1	030090241	030090285					3	Front Plate	1	020070036R	020070036R	
18	Fan Capacitor	1	030010034	030010034					2	Grill Clip	8	109990256R	109990256R	
17	Capactor clamp	1	020140010R	020140010R					1	Front Grill	1	020120001R	020120001R	
41	Maintenance plate	1	980130056R	971300089R										
40	Base	1	313011072R	313011072										
39	Gasket	1	150030009R	150030009R										
38	Nut	1	150020003R	150020003R										
Serial Number	Part Name	Quantity	Cooling Only	Heat Pump	Serial Number	Part Name	Quantity	Cooling Only	Heat Pump	Serial Number	Part Name	Quantity	Cooling Only	Heat Pump